




BUSTER 2000

Ref. No. 17000

MORE INFORMATION:
www.sigmasport.com



CONTENTS




BUSTER 2000
(IP44)



BUSTER 2000 BATTERY PACK
(IP44) Ref. No. 17004



BUSTER 2000 CHARGER
(IP20) Ref. No. 17005



Extension cable




Remote control
(IP44) Ref. No. 17002


1 BURNTIME




2 BATTERY STATUS




3 FLUORESCENT BUTTON



4 START-UP



ATTENTION



Do not stare at the operating light source.







5 OVERHEATING





> 59 °C

AUTO-FUNCTION	
59 °C (100 %)	0
60 °C (90 %)	0
63 °C (80 %)	0
66 °C (70 %)	0
69 °C (60 %)	0
72 °C (50 %)	0
75 °C (5 %)	0



SCREW BRACKET



HELMET BRACKET




BUSTER 2000 ADAPTER FOR ACTION CAMERA MOUNT




BATTERY PACK
(Manufacturer:
SIGMA ELEKTRO GmbH)


1 BATTERY STATUS



2 CHARGING



3 USB CHARGING




Output only
USB

Micro USB cable not incl.

Device not included

You have to push the button, once, before charging can start.
The charging starts, but without pushing no charging.


4 USB SILICONE PLUG




IP44
Close waterproof

Please always keep the silicone plug closed after charging.

5 INSTALLATION







SIGMA BIKE COMPUTER ATS / STS



REMOTE CONTROL


1 PAIRING




2 MODI



3 INSTALLATION






4 REMOTE BATTERY INDICATOR



5 BATTERY CHANGE



6 SLEEP MODE



7 FLUORESCENT BUTTON

